## **SIZING**

To determine required wattage, use the following equation:

GPM X TEMP RISE (°F) X 0.147 = kW REQUIRED

LPM X TEMP RISE (°C) X .07 = kW REQUIRED

Temperature rise is expressed in degrees F where GPM is gallons per minute of flow desired. Round results up to select unit.

Example: 2.5 GPM x 95°F x 0.147 = 35 kW (Use 36 kW)

CONSULT OUR FACTORY FOR DETAILED SIZING INFORMATION AND APPLICATION ASSISTANCE.